

## **ALUMI-WOOD RAILING SYSTEMS INSTALLATION INSTRUCTIONS**

- 1. DETERMINE QUANTITY OF RAIL AND NUMBER OF POSTS REQUIRED.**
- 2. REMOVE PANELS FROM BOX AND MEASURE DESIRED OPENING TO DETERMINE SPACING OF PANELS AND NUMBER OF POSTS TO BE USED.**
- 3. CUT PANEL OR PANELS TO PROPER DIMENSIONS AND REINSTALL CLIPS AT ENDS IF NECESSARY.**
- 4. IF USING CENTER POST SCREW PANELS TO POST USING ENCLOSED FASTENERS NOW OR GO TO STEP 5.**
- 5. IF MOUNTING TO COLUMNS MARK A HORIZONTAL LINE ON THE COLUMN AT 36". THIS WILL BE THE TOP OF RAIL SETTING LOCATION.**
- 6. INSTALL RAIL TO COLUMNS OR WALLS USING PROPER FASTENERS PER FIELD CONDITIONS.**
- 7. PUT ALL BOLTS IN FLOOR FLANGES.**
- 8. IF APPLICABLE, MEASURE FOR STEP RAILS USING SUPPLIED FORM AND FAX OR MAIL TO CUSTOM ORNAMENTAL IRON, INC.**
- 9. CUSTOM MADE STEP RAILS TAKE APPROXIMATELY 2 WEEKS FOR DELIVERY, F.O.B. GLEN ALLEN, VIRGINIA.**
- 10. INSTALL STEP RAIL TO INSURE THAT ALL MEMBERS ARE LEVEL AND CONSISTENT.**
- 11. ENJOY YOUR NEW POWDERCOATED ALUMINUM HANDRAILING.**